

BREEZE.AI

Breeze Workspace

Smarter estimating and job management for electrical contractors, from the first drawing to the final invoice.

WEB

breezeestimating.ai

EMAIL

info@breezeestimating.ai

INSIDE

- 01 Our application
- 02 One system from drawing to billing
- 03 Everything the office and field need
- 04 The tech mobile app
- 05 What makes Breeze different

Smarter software. Stronger projects.

Sign up, set up and start a takeoff

01	Pick a plan	Choose Basic, Growth or Platinum on the pricing page and click Sign Up.
02	Create account	Enter full name, email and password.
03	Company profile	Name, business address, contact, phone, email and time zone.
04	Accept terms	Agree to Terms of Service and Privacy Policy; signer and date recorded.
05	Set up payment	Confirm the plan, set the number of seats, choose Monthly or Annual.
06	Check out	Enter card and billing address on Stripe's secure page, then Subscribe.
07	Confirmed	See plan, seats, receipt and next billing date. Click Continue to Setup.
08	Invite the crew	Add name, email, role and team for each member. Send invitations.
09	Load prices	Upload an existing price list, or add commodity items one by one.
10	Add a client	Client name, contacts, labor rate and site addresses.
11	Add a project	Pick the client and name the project; add dates, team and members.
12	Upload drawings	In AI Takeoff, choose the project, add the drawing PDF and start.

Estimate, run, track and bill the job

13	Review takeoff	Approve, reject or adjust each item and quantity the AI detected.
14	Check estimate	Review the estimate built from the takeoff and rates; add addenda.
15	Create the job	Set site, dates, team and job type. Tasks go to that crew.
16	Track jobs	Jobs list shows status, progress, crew, schedule and open tasks.
17	Manage tasks	Assign foreman and journeyman, due date and planned hours.
18	Schedule on calendar	Jobs appear by day automatically from each crew and date.
19	Job overview	Value, cost, margin, progress, bill of quantities and activity.
20	Raise a change order	Add reason, materials and labor; markup sets the sell amount.
21	Approve change order	Approve or reject; the approved amount goes on the job's billing.
22	Electrical tools	Panel mapping, conduit fill, voltage drop and measurement calculator.
23	Log time	Job, task, date, start and end time, break; mark it billable.
24	Approve time	Submit, then approve or reject; hours roll up to the job.
25	Invoice and get paid	Create invoices; track outstanding, overdue and paid amounts.

One system from drawing to billing

	BREEZE WORKSPACE	THE USUAL WAY
Takeoff	AI reads the drawings and counts every item	Counting symbols by hand, sheet by sheet
Pricing	Priced from your own price list and labor rates	Copying prices into spreadsheets
Estimate to job	Signed-off review becomes the estimate, then the job	Re-keying the same numbers in another tool
Scheduling	Jobs land on the crew calendar automatically	Whiteboards and phone calls
Change orders	Costed, approved and added to the job's billing	Email threads and paper forms
Time	Logged against tasks, approved, rolled up to the job	Separate timesheets reconciled later
Field math	NEC calculators built in, tied to the project	Separate apps and reference tables

Everything the office and field need

AI Takeoff PLATINUM Upload a drawing PDF; the AI finds symbols, counts and wire sizes for you to review.	Estimates and addenda Priced from your rates, with markup, tax and addenda kept on one estimate.	Jobs, tasks and calendar Create jobs, assign crews and tasks, and see every crew's schedule by day.
Change orders Capture extra materials and labor, set markup, then approve and bill.	Time tracking Crews log hours against tasks; approvals split regular and overtime.	Electrical tools Panel mapping, conduit fill, voltage drop and measurement calculators.
Plans per user / month, billed annually Basic \$150 · Growth \$300 · Platinum \$500		

The crew's day, in their pocket

Built for

Foremen

Journeyman

Apprentices

01

Auto-assigned jobs and tasks

Each crew member's jobs and tasks show up on their phone as soon as they're scheduled.

02

Geofenced check-ins

Check-in and check-out happen at the job site location, so hours are tied to where the work is.

03

Real-time status updates

Job and task progress from the field reaches the office the moment it changes.

04

Offline mode

Keep working with no signal; updates sync when the phone is back online.

What makes Breeze different

Use your own price list

Upload it in any format. No retyping.

AI counts for you

Upload drawings. The AI counts the parts and wire.

Prices for each project

Set special prices for one project if needed.

Extra scope, one job

Add drawing changes to the same job.

See your profit

Every job shows its value, cost and profit.

Extra work, with proof

Add photos or emails. Get it approved and billed.

Smart calendar

Jobs go on the calendar by themselves. Clashes are flagged.

Overtime done for you

Hours are split into regular and overtime.

GET IN TOUCH

Let's get your crew on Breeze

Book a demo and see your own drawings turned into an estimate.



SCAN TO CONNECT

WEB

breezeestimating.ai

EMAIL

info@breezeestimating.ai

PHONE

(614) 512-1635